





5.

- Assemble the thick board to the thin board with 4 long poles. Tighten 4 screws to secure 4 long poles to the thick board. Attach the cushion onto 4 screws.
- 2. Assemble another thin board to the last thin board with screwing another 4 long poles to tighten. Follow the same steps for the board with socket.
- Assemble the wood frame to the socket frame with screwing 4 long poles to tighten. Fasten 4 screws to secure the wood frame to 4 long poles. Attach the shade peg onto 4 screws.
- 4. Set small poles into socket frame and then insert the shade.
- 5. The lamp is completed.



3.



4.





A. Cushion	C. Thick board	E. Threaded screw	G. Board with socket	I. Wood frame	K. Shade
\bigcirc		DIJAM	00		
4PCS	1PC	12PCS	1PC	1PC	1PC
B. Screw	D. Long pole	F. Thin board	H. Short pole	J. Shade peg	L. Small pole
()IIIIIIII		$\langle \rangle$		\bigcirc	42220
8PCS	12PCS	2PCS	4PCS	4PCS	4PCS

GENERAL PRODUCT INFORMATION:

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. DO NOT ALTER THE PLUG.

BULB TYPE: (1) 150 watt incandescent or 42 watt CFL equivalent. (not included)