

# ASSEMBLY INSTRUCTION

SKU#: 20087657

DESCRIPTION: BEAUMONT DRESSER & MIRROR

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small hardware which may have come loose inside the carton during shipment. Identify and count all hardware and compare with the hardware list below.


**PARTS LIST**

NO.	Description	Sketch	Quantity
A	Dresser		1PC
B	Mirror		1PC
C	Mirror Support		2PCS

**HARDWARE LIST:**

NO.	Description	Sketch	Quantity
1	Allen bolt Ø1/4"*40mm		8PCS
	Lock washer Ø1/4"*11*2mm		
3	Flat washer Ø1/4"*19*2mm		8PCS
	Allen Key M4		
4			1PC

**STEP 1**





## **WARNING: To avoid serious personal injury**

- \* Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- \* Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children.
- \* Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.