















WARNING: To avoid serious personal injury:








- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

ASSEMBLY INSTRUCTION











Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

*** Do not fully tighten screws until fully assembled ***

COMPONENT PARTS		
DESCRIPTION	PART NAME	QTY (PCS)
①	TOP 	1
②	BACK PANEL UP 	1
③	TOP FRAME 	1
④	DIVISION PANEL 	1
⑤	BOTTOM PANEL 	1
⑥	SHELF 	2
⑦	WINE RACK 	1
⑧	BACK PANEL - DOWN 	1
⑨	SIDE FRAME - LEFT 	1
⑩	SIDE FRAME - RIGHT 	1
⑪	ROD TOWEL 	1
⑫	HOLDER 	2

	COMPONENT PARTS		
DESCRIPTION	PART NAME		QTY (PCS)
(13)	DOOR		1
(14)	DRAWER HEAD		1
(15)	DRAWER BACK PANEL		1
(16)	DRAWER SUPPORT		1
(17)	DRAWER BOTTOM PANEL		1
(18A)	DRAWER SIDE PANEL - LEFT		1
(18B)	DRAWER SIDE PANEL - RIGHT		1

HARDWARE REQUIRED

(A)		BOLT	M6 x 40mm	2 PCS
(B)		BOLT	M6 x 60mm	12 PCS
(C)		BARREL NUT	M6 x 13mm	12 PCS
(D)		FLAT WASHER	1/4"	2 PCS
(E)		ALLEN KEY	M4 x 100mm	1 PC
(F)		WOOD PLUG	10.5Ø	12 PCS
(G)		CHIPBOARD SCREW	M3.5 x 32mm	8 PCS
(H)		MAGNETIC CATCH		1 PC
(I)		CHIPBOARD SCREW	M3 x 16mm	6 PCS
(J)		DOOR SPRING		2 PCS

(K)		CAM-LOCK	9mm	6 PCS
(L)		MINIFIX	24mm	6 PCS
(M)		HANDLE		2 PCS
(N)		TRUSS HEAD	20mm	4 PCS
(O)		SHELF SUPPORT		8 PCS
(P)		CASTER WITH BREAK	50mm	2 PCS
(Q)		CASTER W/O BREAK	50mm	2 PCS




Attention


*** Some number parts listed on the instruction sheet may not to be in parts bag as they already be assembled. Carefully check parts and packing materials prior to ordering replacements.

How to assemble :


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8



STEP 9



STEP 10



STEP 11

