

 **WARNING: To avoid serious personal injury:**

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.


ASSEMBLY INSTRUCTIONS FOR
FLOOR LAMP
Model # AF40804



PLEASE READ AND SAVE THESE INSTRUCTIONS:

Remove all parts from the packaging and lay them on a flat surface.

1. Insert pole 1 (B) into the base (A) and turn it clockwise to tighten.
2. Insert pole 2 (C) into pole 1 (B) and turn it clockwise to secure.
3. Insert pole 3 (D) into pole 2 (C) and turn it clockwise to secure.
4. Insert pole 4 (E) into pole 3 (D) and turn it clockwise to secure.
5. Pull the remaining slack of the power cord out carefully from the base (A).
6. Remove the socket ring (G) from the socket by turning it counterclockwise.
7. Place the shade (F) on top of the socket.
8. Replace the socket ring (G) on the the socket and turn it clockwise to secure the shade (F).



MAINTENANCE:

This lamp requires the use of a maximum 18-Watt LED light bulb or a type A 150-Watt maximum incandescent bulb (not included). Wattages listed are maximum, lower wattages may be used.


IMPORTANT BULB INFORMATION: Do not use halogen light bulbs with this lamp. Halogen bulbs operate at a higher temperature and failure of a halogen bulb may cause smoke and/ or fire damage to the lamp and/ or surroundings.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER PLUG.**


Shade assembly instructions

PLEASE READ AND SAVE THESE INSTRUCTIONS:




STEP 1:

Take the shade out of box and extend it.
Shade requires 4 (G) connectors to assemble.
There are a total of 5 connectors included. One extra is spare.




STEP 3 - Assemble Bottom Ring:

- Press or insert the 2 ends of bottom part into 2 plastic connectors separately.
- Press or insert the 2 ends of top part into the plastic connectors of bottom part separately. Press top uno into the bottom uno.
- Adjust the 2 connectors, make sure the raised portion is facing center of the ring and open side is facing the shade.




STEP 5:

Flip over the shade. Insert the bottom ring down to the bottom of the shade. Keep the 2 connectors away from the (5) open-ended clips on shade. Fix the bottom ring into the (5) open-ended clips.




STEP 2 - Assemble Top Ring:

- Press or insert both ends of A part into 2 plastic connectors separately.
- Press or insert both ends of B part into the above 2 connectors separately.
- Adjust the 2 connectors, make sure the raised portion is facing center of the ring and open side is facing the shade.



STEP 4:

Place the top ring down to the bottom of the shade. Keep the 2 connectors away from the (5) open-ended clips on shade. Fix it into the (5) open-ended clips around the shade.



STEP 6:

The shade is ready.