


Model# 4001-12/18



CAUTION: Once being mounted, do not pull on lamp as this may cause injury to persons and damage to the lamp and mounting surface. To reduce risk of such injury or damage, mount on a surface that is mechanically solid. Fasten mounting hardware to wooden ceiling support beams only. Do not mount to plasterboard.

1. Place the shade (E) onto the socket (D) and tighten it with socket ring (F) .

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG .**

BULB TYPE: Use only with one type A Max 150W bulb (bulbs not included).

WARNING: Do not use cord in wet conditions.

PARTS DIAGRAM

(2) *Screw Anchors (A)
(2)* Screws (B)
(2) * Hanger (C)
(1) *Shade (E)

(1)* Socket (D)
(1)*Socket ring (F)