








WARNING: To avoid serious personal injury:









- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

Product Assembly Instructions


PART LIST

 <p>A : BACKREST x1</p>	 <p>B : CUSHION SEAT x1</p>	 <p>C : SIDE LEG (L & R) x2</p>
 <p>D : FRONT RAIL x1</p>	 <p>E : BACK RAIL x1</p>	


HARDWARE LIST

 <p>F : JCBC SCREW M6 x 25mm x4</p>	 <p>G : JCBC SCREW M6 x 50MM x4</p>	 <p>H : SPRING WASHER 1/4" x8</p>
 <p>I : PAN HEAD WOOD SCREW M5 X 32mm x6</p>	 <p>J : WOOD DOWEL DIA 8 x 25mm x2</p>	 <p>K : WOOD DOWEL DIA 8 x 35mm x8</p>
 <p>L : WOOD BUTTON 14.5MM x4</p>	 <p>M : ALLEN KEY M4 (BALL SHAPE) x1</p>	


STEP 1



STEP 2



STEP 3



STEP 4

