


Branson Tall Cabinet

SKU# 2023032001




WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

WB-20428-CN

MADE IN CHINA

PART LIST



















PART LIST

SPARE PARTS - AVAILABLE FOR REPLACEMENT


#1	TOP PANEL	01
#2	UPPER LEFT FRAME	01
#3	BOTTOM LEFT FRAME	01
#4	UPPER RIGHT FRAME	01
#5	BOTTOM RIGHT FRAME	01
#6	RAIL	02
#7	ADJUSTABLE SHELF - TOP	02
#8	FIXED SHELF	01
#9	ADJUSTABLE SHELF - BOTTOM	02
#10	BOTTOM PANEL	01
#11	DOOR	01
#12	BACK PANEL	02

HARDWARE LIST

A		CAM BOLT	08
B		CAM LOCK	08
C		WOOD DOWEL	04
D		SHELF SUPPORT	16
E		PIN	02
F		SCREW (Ø4 X 25mm)	08
G		SCREW (Ø3.5 X 20mm)	16
H		SCREW (Ø3 X 14mm)	04
I		MAGNET DOOR STOP	01
J		MAGNET PLATE	01
K		STRAP	01
L		SCREW (Ø4 X 12mm)	01
M		SCREW (Ø4 X 50mm)	01
N		FLAT WASHER	02
O		WALL ANCHOR	01
P		SCREW / VIS / TORNILLO (Ø4 X 60mm)	04

NOTE: Find the label of "Hardware Enclosed" on one of the carton corner then follow the red ribbon to get the hardware bag.


TOOLS REQUIRED




PHILIPS SCREWDRIVER		NOT SUPPLIED
---------------------	---	--------------

IMPORTANT:


1. Do not tighten bolts completely until all bolts are completely lined up and inserted into holes / nuts.
2. Do not over tighten screws and bolts to avoid stripping.
3. Please use hand tools to assemble this product. Do not use power tools.
4. For ease of assembly, two adults are recommended

1.




A		08
H		02
I		01



2.




P		04
---	---	----

3.




B		08
C		04


4.






5.




6.




E		02
H		02
J		01

7.







8.




D		16
---	---	----

9.





K		01
L		01
N		01

10.



11.

PLEASE NOTE: For your safety, to prevent the danger of this unit tipping over, it is important that the wall anchors are properly attached.



⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:



- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*

NOTICE

Not intended for clothing storage.



M		01
N		01