
CHRISTY CABINET SIDE TABLE

SKU# 2140040001 SKU# 2140040002 SKU# 2140040003




WPC-20084-VN

MARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

PART LIST



#1	BOTTOM PANEL	01
#2	REAR FRAME	
#3	RIGHT FRAME	
#4	LEFT FRAME	01
#5	BACK PANEL	01
#6	DIVISION PANEL	01
#7	DOOR	01
#8	TOP PANEL	01
#9	SHELF	01
#0	HARDWARE	01

HARDWARE LIST

Α		BOLT (Ø1/4"X1-1/8")	10
В	0	FLAT WASHER (Ø5/8)	10
с	- CD	SHELF SUPPORT PIN	


NOTE: Find the label of "Hardware Enclosed" on one of the carton corner then follow the red ribbon to get the hardware bag.


TOOLS REQUIRED

ALLEN KEY	SUPPLIED
PHILLIP SCREWDRIVER	NOT SUPPLIED


IMPORTANT:


- 1. Do not tighten bolts completely until all bolts are completely lined up and inserted into holes / nuts.
- 2. Do not over tighten screws and bolts to avoid stripping.
- 3. Please use hand tools to assemble this product. Do not use power tools.
- 4. For ease of assembly, two adults are recommended







4.




















ASSEMBLY COMPLETED



MaxImun Weight 10 lbs

Tighten bolts firmly.

Do not overtighten the bolts and screws.