
Flachnan Jewelry Armoire

SKU# 2140010001






WARNING: To avoid serious personal injury:

- · Carefully and strictly followsssembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children.
 Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

HFP-20452-CN

PART LIST



SPARE PARTS - AVAILABLE FOR REPLACEMENT

#2	TOP PANEL	01
#3	FRONT LEG	02
#4	BACK LEG	02
#5	LEFT DOOR	01
#6	RIGHT DOOR	01
#7	SMALL DRAWER WITH 6 SQUARES	01
#8	SMALL DRAWER	01
#9	LARGE DRAWER	02

SPARE PARTS - NOT AVAILABLE FOR REPLACEMENT

#1 CABINET	01	
------------	----	--

HARDWARE LIST

Α		BOLT (Ø1/4"x1-9/16")	08
В	Emmm-	SCREW (Ø1/8"x5/8")	03
С		FLAT WASHER	08
D		FOAM PAD	02
E		WALL ANCHORS	01
F		SCREW (Ø5/32"x2-3/8")	01
G		SPRING WASHER	08


TOOLS REQUIRED


PHILIPS SCREWDRIVER NOT SUPPLIED

IMPORTANT:

- 1. Do not tighten bolts completely until all bolts are completely lined up and inserted into holes / nuts.
- 2. Do not over tighten screws and bolts to avoid stripping.
- 3. Please use hand tools to assemble this product. Do not use power tools.
- 4. For ease of assembly, two adults are recommended

1.







3.

PLEASE NOTE: For your safety, to prevent the danger of this unit tipping over, it is important that the wall anchors are properly attached.

Children have died from furniture tipover. To reduce the risk of furniture tipover: - ALWAYS install tipover restraint provided. - NEVER put a TV on this product. - NEVER allow children to stand, climb or hang on drawers, doors, or shelves. - NEVER open more than one drawer at a time. - Place heaviest items in the lowest drawers. This is a permanent label. Do not remove!





E	01
F	01