


Frankie Large White Two Door Cabinet


SKU# 2259002003



WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
 - Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
 - Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.
-

















PART LIST



#1	TOP PANEL	01
#2	LEFT FRAME	01
#3	RIGHT FRAME	01
#4	ADJUSTABLE SHELF	02
#5	BOTTOM PANEL	01
#6	UPPER RAIL	01
#7	BOTTOM RAIL	01
#8	BACK PANEL - RIGHT	01

#9	BACK PANEL - LEFT	01
#10	LEFT DOOR	01
#11	RIGHT DOOR	01
#12	BRACE	01

HARDWARE LIST

A		CAM BOLT	16
B		CAM LOCK	16
C		WOOD DOWEL (Ø6X30mm)	12
D		MAGNET DOOR STOP	01
E		SCREW (3X12mm)	66
F		HINGE	04
H		KNOB	02
I		BOLT (4X22mm)	02
J		MAGNET PLATE	02
N		SCREW (4X60mm)	01
O		WALL ANCHOR	01
Q		HOOK	02
R		CLIP	02
T		SHELF SUPPORT	08
U		SCREW (4X12mm)	01
V		METAL PLATE	01

NOTE: Find the label of "Hardware Enclosed" on one of the carton corner then follow the red ribbon to get the hardware bag.

TOOLS REQUIRED

PHILIPS SCREWDRIVER







NOT SUPPLIED

IMPORTANT:


- 1. Do not tighten bolts completely until all bolts are completely lined up and inserted into holes / nuts.
- 2. Do not over tighten screws and bolts to avoid stripping.
- 3. Please use hand tools to assemble this product. Do not use power tools.
- 4. For ease of assembly, two adults are recommended

1.




A		16
U		01
V		01

2.






3.




B		02
---	--	----



4.





B		04
C		04



5.





B		04
C		04

6.








B		06
C		04

7.




T		08
---	---	----

8.



E		28
F		04
H		02
I		02
J		02
R		02

9.




E





08

10.



11.



E		24
---	---	----

12.

PLEASE NOTE:

For your safety, to prevent the danger of this unit tipping over, it is important that the wall anchors are properly attached. Not intended for clothing storage.




⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*





N		01
O		01