
Frankie Small Gray One Door Cabinet

SKU# 2258063001






WARNING: To avoid serious personal injury:

- · Carefully and strictly followsssembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- · Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- · Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

PART LIST



#1	TOP PANEL	01
#2	LEFT FRAME	01
#3	RIGHT FRAME	01
#4	SHELF	02
#5	BOTTOM PANEL	01
#6	APRON	01
#7	BACK PANEL	01
#8	DOOR	01


HARDWARE LIST

Α		CAM BOLT	12
В	×	CAM LOCK	12

С		WOOD DOWEL (Ø6X30mm)	12
D		MAGNET DOOR STOP	01
E	(%)	SCREW (3X12mm)	42
F	0 0 0	HINGE	02
Н		KNOB	01
I		BOLT (4X22mm)	01
J	0 0	MAGNET PLATE	01
К		SHELF SUPPORT	08
L	(11111)	SCREW (4X12mm)	01
М		METAL PLATE	01
N	<i> </i>	SCREW (4X60mm)	01
0		WALL ANCHOR	01
Q		ноок	01
R		CLIP	01


NOTE: Find the label of "Hardware Enclosed" on one of the carton corner then follow the red ribbon to get the hardware bag.


TOOLS REQUIRED





IMPORTANT:


- 1. Do not tighten bolts completely until all bolts are completely lined up and inserted into holes / nuts.
- 2. Do not over tighten screws and bolts to avoid stripping.
- 3. Please use hand tools to assemble this product. Do not use power tools.
- 4. For ease of assembly, two adults are recommended




















PLEASE NOTE:

For your safety, to prevent the danger of this unit tipping over, it is important that the wall anchors are properly attached. Not intended for clothing storage.

Children have died from furniture tipover. To reduce the risk of furniture tipover: - ALWAYS install tipover restraint provided. - NEVER put a TV on this product. - NEVER allow children to stand, climb or hang on drawers, doors, or shelves. - NEVER open more than one drawer at a time. - Place heaviest items in the lowest drawers. This is a permanent label. Do not remove!

