
# Hadley Brown Adjustable Height Backless Stool

## SKU# 2258054002






#### WARNING: To avoid serious personal injury:

- · Carefully and strictly followsssembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

#### **PART LIST**



#1	SEAT	01
#2	LEG	04
#3	SEAT	01
#4	LEG	04
#5	LEG	04

#### **HARDWARE LIST**

Α	BOLT (Ø1/4"x3/4")	04
В	BOLT (Ø1/4"x3/4")	16
С	SPRING WASHER	04
D	FLAT WASHER	04

**NOTE:** Find the label of "Hardware Enclosed" on one of the carton corner then follow the red ribbon to get the hardware bag.


#### **TOOLS REQUIRED**


ALLEN KEY	SUPPLIED

#### **IMPORTANT:**

- 1. Do not tighten bolts completely until all bolts are completely lined up and inserted into holes / nuts.
- 2. Do not over tighten screws and bolts to avoid stripping.
- 3. Please use hand tools to assemble this product. Do not use power tools.
- 4. For ease of assembly, two adults are recommended

### 1.







Do not fully tighten the bolts.

B 08

2.







Do not fully tighten the bolts.


В 04

3.





Tighten bolts firmly.



6. Maximum Weight 225 lbs

