


June Ivory Storage Bench

SKU# 2014107001




HLC-20167-VN

⚠ WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

PART LIST





#1	TOP PANEL	01
#2	RIGHT SIDE PANEL	01
#3	LEFT SIDE PANEL	01
#4	BACK PANEL	01
#5	RIGHT DIVIDER PANEL	01
#6	LEFT DIVIDER PANEL	01
#7	BOTTOM RAIL	01
#8	TOP RAIL	01
#9	MIDDLE BOTTOM PANEL	01
#10	SIDE BOTTOM PANEL	02
#11	SLIDING DOOR	02
#12	SHELF	01
#13	CUSHION	01

HARDWARE LIST

A		WOOD SCREW (Ø1/4" X 2-3/8")	08
B		BOLT (Ø1/4" X 1-1/4")	06
C		FLAT WASHER	06
D		SPRING WASHER	06
E		WOOD PLUG	08
F		SHELF PIN	04
G		SCREW (Ø4 X 25MM)	04

NOTE: Find the label of "Hardware Enclosed" on one of the carton corner then follow the red ribbon to get the hardware bag.


TOOLS REQUIRED

ALLEN KEY		SUPPLIED
PHILLIP SCREWDRIVER		NOT SUPPLIED


IMPORTANT:

1. Do not tighten bolts completely until all bolts are completely lined up and inserted into holes / nuts.
2. Do not over tighten screws and bolts to avoid stripping.
3. Please use hand tools to assemble this product. Do not use power tools.
4. For ease of assembly, two adults are recommended


1.




2.






3.





A		02
---	---	----




4.




A		04
G		04

5.





B		06
C		06
D		06

6.




7.




8.

PUSH LATCH WITH INDEX FINGER





9.

PUSH LATCH WITH INDEX FINGER



10.



Maximum Weight 275 lbs

