



WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

ITEM NO.:LS-83116/3PK

ASSEMBLY INSTRUCTIONS

Carefully unpack this lamp and place it on a flat surface.

TABLE LAMP

1. Attach the shade (2) onto socket (1) and secure it with socket ring (3). Install the bulb (4) into socket (1).

FLOOR LAMP

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A FLAT SURFACE AND LINE THEM UP AS PER THE SKETCH
2. SCREW TUBE (B),TUBE(C)AND LIGHT POLE(D)INTO BASE(A)IN TURN,PULL THE WIRE OUT FROM BOTTOM OF THE BASE(A)
3. ATTACH THE GLASS SHADE(E)ON THE SOCKET(H)AND SECURE SOCKET RING(F)
4. INSERT BULB (G)(INCLUDED) INTO SOCKET(H)
5. INSERT THE POLARIZED PLUG INTO WALL OUTLET;TURN ON THE SWITCH AND ENJOY YOUR NEW LAMP

Use a 60W*3pcs (Maximum) Edison S19 Type Bulb.(Bulbs included)

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other)as safety a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

ATTENTION:

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DECOURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES A FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT.

✘ PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

✘ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

