



WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

ITEM NO.: LS-83825

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack and place all lamp parts on a flat surface.
2. Attach base(E), clump weight(D), Shim(B&C) onto column(F) and secure them together with nut(A) by wrench (G).
3. Insert lamp body (H & I) into column(F).
4. Connect the power cord from the column(F) to the power cord of switch(J).
5. Connect the power cord of switch(J) to the power cord of adapter(K).

CAUTION: THE POWER CORD OF THE ADAPTER(K) CAN NOT CONNECT WITH THE POWER CORD FROM THE COLUMN(F) DIRECTLY!

6. Plug into outlet, turn on the switch and enjoy your new lamp.

USE 18 W (MAXIMUM) LED (INCLUDED)

I+H=18W

※ PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

