


PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.



A. Backrest
2x



B. Seat
2x



C. Arm
4x



D. Bolt M6 x 40
20x




F. Chair Washer
20x



G. Cushion
2x



H. Table Frame
1x



I. Table Legs
2x




J. Table Side
2x



K. Table Bolt
12x



L. Table Washer
12x




M. Allen Key
1x




N. Glass
1x

Do not fully tighten bolts until assembly is complete.

1 Attach Arm sides (C) to back rest (A) and Seat (B) using bolts (D) and washers (F)




2 Attach Arms (C) to back rest (A) using bolts (E) and Washers (F)




*Repeat steps 1-2 for the second Single Seater.

- 3** Attache Table legs (I) to table Frame (H) and Table Sides (J) using Bolts (K) and washers (L), Place table glass onto of table frame once assembled




- 4** Place Cushions onto assembled chair frames and enjoy your new outdoor seating.



⚠ WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.



ASSEMBLY INSTRUCTIONS