
WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small
 parts and hardware that may present a choking hazard to small children.
 Bob's furniture should be assembled only by responsible adults and children
 should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as
 prescribed in these instructions to anchor furniture to wall. Proper use of the
 wall mounting hardware can significantly reduce the potential for furniture
 tip-over and crushing injuries.

INSTRUCTION MANUAL



10 Ft. Cantilever Hanging Patio Umbrella With Solar LED

SKU: 0S3002


(!) CARE & MAINTENANCE

- \triangle Clean with lukewarm water, mild detergent & Sponge.
- \triangle Wipe down the pole with damp cloth.
- \triangle Store in a location when not in use.


(!) SAFETY PRECAUTIONS


- \triangle Store the umbrella in windy or stormy weather.
- \triangle Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- \triangle Do not allow umbrella to flap in the wind as it may cause damage.
- \triangle When adjusting umbrella, make sure no person or item is close to avoid injury or damage.

HARDWARE














PARTS












Attention: Part C Solar Panel is packed separately in the white box.



Place part D and E Cross Base as below and attach part B Extend Pole to part E Cross Base with 2 PCS of part 1 bolt and part 2 washer.

Then attach part B Extend Pole to part D Cross Base with 2 PCS of part 1 bolt and part 2 washer.




2


Turn the crank at the end of supporting pole clockwise to pull the umbrella up to the top socket.

Plug the white cable end into the Solar Panel and turn clock-wise to attach the solar panel.

Now you can pull up the umbrella body upward.








4

Unlock the adjusting handle and adjust the supporting pole up and down to a suitable position by pushing the handle upwards or downwards as below .


 \triangle Hold the umbrella supporting pole when adjusting to avoid any injury or damage.





Lock down the adjusting handle when the umbrella supporting pole is in a suitable position as below.


Turn the crank at the end of supporting pole clockwise to open the umbrella while turn anti-clockwise to close the umbrella.



6

Push the supporting pole upward to make the connecting pole straight.


Pull the lock downward to fix the connecting pole firmly.





Press the ON/OFF button to turn on or turn off the LED light.

Now enjoy your time.



ATTENTION:

- · You must charge batteries before first use.
- Please note that batteries can discharge if they are left unused or uncharged for a long period of time. We recommend you charge your solar umbrella for at least 8 hours in direct sunlight before the first use. Failure to charge the batteries will result in premature dimming of the lights in your new solar umbrella.

MAKE SURE THE LIGHT SWITCH IS IN THE OFF POSITION WHEN CHARGING.

• For everyday normal use, turn on the light switch at nighttime when you want to use the solar light and turn off the light switch after every use.

MAKE SURE THE LIGHT SWITCH IS IN THE OFF POSITION IN THE DAYTIME FOR THE SOLAR PANEL TO RECHARGE THE BATTERIES.