



 WARNING: To avoid serious personal injury:


- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)
								A.  M6×20mm x4 B.  M6×30mm x4 C.  M8×45mm x4 D.  white 8mm x2 E.  black 6mm x8 F.  M6 x1 G.  M8 x1 H.  M6 x1 (staight allen key)
x1	x1	x1	x1	x1	x1	x1	x5	

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE


I
REMOVE THE CAP BEFORE ASSEMBLY




II (H) is for use with a power drill



III (H) is for use with a power drill



IV



V



VI

