


CAUTION: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PART LIST			
NO.	PART DESC	CODE	Q'TY
A	DINING SIDE CHAIR W/GREY FABRIC IN BLACK-BACK FRAME WITH CUSHION	PD-1760-8-SCBFR1	1
	DINING SIDE CHAIR W/CHARCOAL PU IN BLACK-BACK FRAME WITH CUSHION	PD-1760-8-SCBFR2	1
B	DINING SIDE CHAIR W/GREY FABRIC IN BLACK-SEAT FRAME WITH CUSHION	PD-1760-8-SCSEA1	1
	DINING SIDE CHAIR W/CHARCOAL PU IN BLACK-SEAT FRAME WITH CUSHION	PD-1760-8-SCSEA2	1
C	SIDE CHAIR - FRONT LEGS IN BLACK	PD-1760-8-SCLEG	2
D	SIDE CHAIR - LEFT & RIGHT STRETCHER IN BLACK	PD-1760-8-SCSTR	2

HARDWARE LIST			
NO.	HARDWARE DESC	CODE	Q'TY
1	 BOLT Ø5/16"x85mm	PD-1760-SCHW	4
2	 BOLT Ø5/16"x38mm		2
3	 BOLT Ø5/16"x50mm		4
4	 LOCK WASHER Ø5/16"		10
5	 FLAT WASHER Ø5/16"		10
6	 ALLEN KEY M5		1
7	 SCREW Ø4x45mm		4

STEP 1




STEP 2




**Assembly Instruction for
DINING SIDE CHAIR
D-1760-8-SC1/D-1760-8-SC2**

STEP 3



COMPLETED



WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provide, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

 **WARNING: To avoid serious personal injury:**

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.