Assembly Instructions

BOB'S FURNITURE


Power Chairside Table

Caution: Please read instructions thoroughly before unpacking assembly parts. Exposed staple tips can cause injury.

- 1. We recommend that you assemble this product with the assistance of another person; this will make assembly easier and will help to eliminate damage to the product or injury to persons during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please put all parts on a non-abrasive surface before assembling and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Code	Hardware		Qty
Α	BOLT 5/16"*63 mm		8
В	SPRING WASHER 5/16"	0	8
С	FLAT WASHER 5/16"	0	8
D	ALLEN KEY 4mm		1

Code	Part	Qty
E	Chairside Table	1
F	Leg	4
G	Power and USB Outlet (Pre-Installed)	1



Hardware Pack Location(s):

Power Chairside Table

WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small
 parts and hardware that may present a choking hazard to small children.
 Bob's furniture should be assembled only by responsible adults and children
 should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as
 prescribed in these instructions to anchor furniture to wall. Proper use of the
 wall mounting hardware can significantly reduce the potential for furniture
 tip-over and crushing injuries.