


ITEM NO.:20092862/ Reagan Brown 3-Arc Floor Lamp

⚠ WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

COMPONENT LIST



Wrench x 1pc




1. Nut x 1pc



2. Metal Washer x 1pc



4. Cover x 1pc



8. Shade Ring x 3pcs



8. Shade Ring x 6pcs



6. Screw x 1pc



9. Bracket x 12pcs




10. Screw x 36pcs





11. Metal Cap x 36pcs



12. Ring x 3pcs



14. Washer x 1pc



ASSEMBLY INSTRUCTIONS

1. Carefully unpack this lamp and place it on a flat surface.
2. Attach cover(4), marble base(3) , metal washer(2) and washer(14) onto pole(5) and secure them together with nut(1) by Wrench 17(wrench included).
3. Connect pole(7) to pole(5) together and secure with screw(6) .
4. Place the bracket(9) on 3pcs shade ring(8) and insert the screw(10) and then secure together with the metal cap(11).
5. Attach the shade onto socket and secure it with ring(12).
6. Install the bulbs(13) into sockets. Insert the polarized plug into wall outlet, turn on the switch and enjoy your new lamp.

※ Use 3pcs 60W (Maximum) Edison ST64 Type Bulbs (Not Included)
or 3pcs Equivalent Energy-Saving Bulbs (Not Included).

IMPORTANT SAFETY INSTRUCTIONS:

This lamp has a polarized plug (one blade is wider than the other) as safety a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

ATTENTION:

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DECOURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES A FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

