


# ITEM NO.:20092876/ Reagan White Table Lamp

**⚠ WARNING: To avoid serious personal injury:**

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

## COMPONENT LIST



4. Shade Ring x 1pc



4. Shade Ring x 2pcs



5. Bracket x 4pcs



6. Screw x 12pcs



7. Metal Cap x 12pcs



8. Ring x 1pc

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## ASSEMBLY INSTRUCTIONS:

1. Carefully unpack this lamp and place it on a flat surface.
2. Connect the metal base(1) and poles(2 & 3) together.
3. Place the bracket(5) on 3pcs shade ring(4) and insert the screw(6) and then secure together with the metal cap(7).
4. Attach the shade onto socket and secure it with ring(8).
5. Install the bulb(9) into socket.
6. Insert the polarized plug into wall outlet, turn on the switch and enjoy your new lamp.

**※Use a 60W (Maximum) Edison ST64 Type Bulb (Not Included)  
or a Equivalent Energy-Saving Bulb ( Not Included).**


## IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as safety a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

## ATTENTION:

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES A FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.



**BOB'S** DISCOUNT FURNITURE