





ASSEMBLY INSTRUCTIONS




BOB'S DISCOUNT
FURNITURE

WENTWORTH - 54" CONSOLE
WENTWORTH - 64" CONSOLE


Caution: Please fully read instructions before unpacking assembly parts.

1. We recommend that you assemble this product with the assistance of another person to avoid injury and prevent damage to the product.
2. Be sure to check all packing materials carefully for small parts or hardware that may have come loose inside the carton during shipment.
3. Please put all parts on a non-abrasive surface before assembling. Follow the steps to assemble your newly purchased product correctly.

1	Allen Key 4mm		1
2	Bolt Ø5/16" x 20 x 7/8"		8
3	Spring Washer Ø5/16"		8
4	Flat Washer Ø5/16"		8

No.	Part		Qty
A	Console		1
B	Foot		4
C	Centre Support Leg		1

STEP 1 :
Attach the Foot (B) to the Console (A) using the provided hardware as shown. Adjust the levelers as necessary.



Hardware Pack Location(s):
WENTWORTH - 54" CONSOLE
WENTWORTH - 64" CONSOLE


ASSEMBLY INSTRUCTIONS

BOB'S DISCOUNT
FURNITURE


WENTWORTH - 54" CONSOLE
WENTWORTH - 64" CONSOLE

Caution: Please fully read instructions before unpacking assembly parts.


1. We recommend that you assemble this product with the assistance of another person to avoid injury and prevent damage to the product.
2. Be sure to check all packing materials carefully for small parts or hardware that may have come loose inside the carton during shipment.
3. Please put all parts on a non-abrasive surface before assembling. Follow the steps to assemble your newly purchased product correctly.



Note:
To adjust the height of the shelf, remove the screw and move the shelf pins. Reinstall screw once you have moved the shelf pins.



★ Remark: There is a tip restraint kit provided on the back of this product. Please thoroughly read the directions and install immediately when placed in home.



Hardware Pack Location(s):

WENTWORTH - 54" CONSOLE
WENTWORTH - 64" CONSOLE



WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.