

## Assembly instructions for CHINA HUTCH


Page 1 of 1


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts.
- 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.
- · Do not allow children to climb on furniture.
- · Do not place television sets on top of chests, door chests and/or dressers.
- · Please place heaviest objects in the lowest drawers.
- · Please have no more than one drawer open at a time.

Part Lists							
No	Part Sketch Q"		Q'Ty				
Α		Hutch	1 pc				
В		Base	1 pc				

No		Q'Ty	
1		(Ø1/4" x 18 x 3/4") Bolt	2 pcs
		(Ø1/4" x 11mm) Spring Washer	2 pcs
		(Ø1/4" x 19 x 2mm) FLat Washer	2 pcs
2		Tipping Resraint Kit	2 set
3		Allen Key	1 pc





Remark: There is a tip restraint kit provided on the back of this product. Please read the directions thoroughly and install immediately when placed in home

## **CHINA BASE**

Page 1 of 1


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


- 1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts.
- 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.
- · Do not allow children to climb on furniture.
- · Do not place television sets on top of chests, door chests and/or dressers.
- · Please place heaviest objects in the lowest drawers.
- · Please have no more than one drawer open at a time.

Part Lists							
No	Part	Sketch	Q'Ty				
А		Base	1 pc				
В		Front Feet	2 pcs				
С		Back Feet 1 LSF/ 1 RSF	2 pcs				

No		Q'Ty	
1		(Ø5/16" x 18 x 2-1/4") Bolt	8 pcs
		(Ø5/16" x 13mm) Spring Washer	8 pcs
		(Ø5/16" x 19 x 2mm) FLat Washer	8 pcs
2		Allen Key	1 pc

Step 2







## ⚠ WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor fumiture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.