

Assembly Instruction for

8-DRAWER DRESSER W/ JEWELRY TRAY

10001367002 & 10001368002

⚠️ WARNING: To avoid serious personal injury:


- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

PART LIST			
NO.	PART DESC	CODE.	Q'TY
A	Dresser	B-14770-5-DR B-14770-7-DR	1
B	Leg	PB-14770-5-CGFET PB-14770-7-CGFET	4
C	Center Support Leg with Leveler	PB-14770-5-DRSPL PB-14770-7-DRSPL	1


HARDWARE LIST			
NO.	HARDWARE DESC	CODE.	Q'TY
1	ANTI - TIP KIT - METAL (SET)	P-ATKNMC-M	1

⚠️ Only tighten all bolts when all bolts aligned with bolt inserts.

STEP 1



STEP 2



COMPLETED

