




WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

INSTRUCTION MANUAL



Outdoor Poly Adirondack Coffee Table
SKU: 2001-CT

! NOTICE

Do not overtighten screws. (Insert all screws before tighten screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Avoid using strong power tool for avoiding to crack the PE board when assembling.

TOOLS REQUIRED



PHILLIPS SCREWDRIVER
(PROVIDED)



TABLE
220 LBS
CAPACITY



1 PERSON
ASSEMBLY




UP TO 20 MIN.
ASSEMBLY

HARDWARE

1

M4x45mm
SCREW



12 PCS

2

PHILLIPS
SCREWDRIVER




1 PC

PARTS

A


TABLE TOP



1 PC

B


TABLE LEG



2 PCS

C

WOODEN BRACE




2 PCS

PRODUCT ASSEMBLY

1


Attach part B Table Leg to part A Table Top with 4 PCS of part 1 screw using a phillips screwdriver.

Do not tighten screws too much at this stage.



2

Attach part C Table Wooden Braces to part B Chair Leg with 2 PCS of part 1 screw.



PRODUCT ASSEMBLY

3

Attach another part B Table Leg to part A Table Top and part C Wooden brace with 6 PCS of part 1 screw using a phillips scwdriver.

